



4moms® connect high chair®

Whether it's dinnertime, snack time, or any bite in-between, mealtime is the perfect time for families to connect with their new baby. The 4moms® Connect High Chair® keeps baby safe and comfortable, so you can focus on the fun parts of mealtime. Its one-handed tray attachment makes tricky trays a thing of the past, and the new adjustable features grow with baby, so they'll always have a seat at the table.



FEATURES

One-Handed Magnetic Tray Attachment

Magnets guide and lock the tray into place.

GROWS WITH BABY

Adjustable Seat Recline for Newborns

Keep newborns comfortably elevated and involved in all mealtime activities by removing the tray, adjusting to a 3-point harness, and reclining the seat. When baby gets older and can sit up to eat, simply adjust the seat to an upright position, transition to a 5-point harness and add the tray.

Removable Crotch Post for Toddlers

Remove the crotch post to give your growing toddler more room. Lower the chair to its lowest height setting, remove the harness and the tray, and pull the chair directly to your kitchen or dining room table.

Adjustable Height & Tray

Three height positions, and three tray positions.

EASY TO CLEAN

Removable Tray Liner

Removable, top rack dishwasher safe tray liner.

Seat Insert

Easy to clean, removable foam insert.

Weight Restriction: up to 60 pounds

Retail Price: \$299.99 (white/grey color option only)